







Battery Modules	Battery Configuration		Top Cover	Battery Modules	Floor Stand (optional)	Cable to Inverter	Cable to Battery to Battery	Cable Tower to Tower
			IAC-RBAT-5KMTOP-01	BAT-05K48S0B-01	IAC-RBAT-5KFSTD-01	IAC-RBAT-5KCINV-01	IAC-RBAT-5KCBAT-01	IAC-RBAT-5KCTOW-01
1	1		1	1	1	1	0	0
2	2		1	2	1	1	1	0
3	3		1	3	1	1	2	0
4	2+2		2	4	2	1	2	1

Battery Modules	Battery Configuration		Top Cover	Battery Modules	Floor Stand (optional)	Cable to Inverter	Cable to Battery to Battery	Cable Tower to Tower
	3+1							
5	3+2		2	5	2	1	3	1